

How to Uncrate a Barudan BEKT-S1501CAII (XL) Embroidery Machine



1. Machines arrive by common carrier in an enclosed wooden crate. If there is no loading dock, a liftgate can be provided.



4. The pieces consist of two sides, two interchangeable support braces (front and rear) and the bottom plate (shown in the lower right hand of the photo).



2. The tools needed to uncrate the machine: drill with 10mm socket, hammer, pry bar, knife and gloves.



5. Assemble the cart with the provided bolts and washers. Use an 8mm hex wrench to tighten the bolts. It should look like this when it is assembled.



3. The machine cart is boxed and banded to the top of the crate. Cut the bands and place the box on the ground. Open the box and unwrap the five pieces for assembly.



6. With the drill and 10mm socket, remove the lag screws from the top of the crate.



7. Once the top of the crate is off, remove the cap accessories and set them aside. Remove the lag screws holding the two wooden beams that supported the top of the crate. The beams are nailed from the back of the crate, so just pry them up and push them to the rear, out of the way. Remove the lag screws from the front of the crate and discard the front panel.



10. With the hammer and pry bar, carefully remove all of the wooden hold down supports from all sides of the machine. Once the hold down supports are removed, the machine will be free from the pallet and ready to be carefully positioned on the cart. Please use assistance when moving the machine.



8. The remaining sides of the crate are nailed. Using the hammer and pry bar, remove the three sides and discard. Next, carefully cut the moisture barrier as close to the bottom of the machine as possible. Remove and discard the moisture barrier.



9. With the sides of the crate removed, cut the yellow banding and set the accessory boxes and thread stand (packed in bubble wrap) aside.